

# MOUNTED SQUARE DEPOT TYPE FERTILIZER SPREADER



**SMFRS-1000DH**



**SMFRS-800SM**




**SMFRS-1000DH**



**SMFRS-400SH**



**SMFRS-400SM**





## GENERAL FEATURES

The fertilizer spreader is used before and after crop planting. The purpose of using the fertilizer spreader is for increasing soil and crop yields. Our fertilizer spreaders, which are connected to the tractor with a three-point suspension system, take their movement from the tractor PTO. Our Fertilizer Spreader, which has high quality gearboxes, receives movement from PTO and transfer it to the disc and performs the fertilizer spreading process with the force generated on the disc.

## TECHNICAL DETAILS

CODE	CAPACITY (LT)	TYPE OF MACHINE	TYPE OF DEPOT	TYPE OF MIXER	TYPE OF GEARBOX	OPEN-CLOSE ADJUSTMENT	WORKING WIDTH	PTO ROTATION (RPM)	REQUIRED POWER (HP)	INOX DISC	TENT
SMFRS-400SM	400	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	MANUAL	16-18 METER	540	40-45	OPTIONAL	OPTIONAL
SMFRS-500SM	500	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	MANUAL	16-18 METER	540	45-55	OPTIONAL	OPTIONAL
SMFRS-600SM	600	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	MANUAL	16-18 METER	540	55-65	OPTIONAL	OPTIONAL
SMFRS-800SM	800	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	MANUAL	16-18 METER	540	65-70	OPTIONAL	OPTIONAL
SMFRS-1000SM	1000	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	MANUAL	16-18 METER	540	70-75	OPTIONAL	OPTIONAL
SMFRS-400SH	400	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	HYDRAULIC	16-18 METER	540	40-45	OPTIONAL	OPTIONAL
SMFRS-500SH	500	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	HYDRAULIC	16-18 METER	540	45-55	OPTIONAL	OPTIONAL
SMFRS-600SH	600	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	HYDRAULIC	16-18 METER	540	55-65	OPTIONAL	OPTIONAL
SMFRS-800SH	800	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	HYDRAULIC	16-18 METER	540	65-70	OPTIONAL	OPTIONAL
SMFRS-1000SH	1000	MOUNTED	SQUARE	VERTICAL	SINGLE DISC	HYDRAULIC	16-18 METER	540	70-75	OPTIONAL	OPTIONAL
SMFRS-500DM	500	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	MANUAL	18-24 METER	540	45-55	OPTIONAL	OPTIONAL
SMFRS-600DM	600	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	MANUAL	18-24 METER	540	55-65	OPTIONAL	OPTIONAL
SMFRS-800DM	800	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	MANUAL	18-24 METER	540	65-70	OPTIONAL	OPTIONAL
SMFRS-1000DM	1000	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	MANUAL	18-24 METER	540	70-75	OPTIONAL	OPTIONAL
SMFRS-1200DM	1200	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	MANUAL	18-24 METER	540	75-80	OPTIONAL	OPTIONAL
SMFRS-1500DM	1500	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	MANUAL	18-24 METER	540	80-85	OPTIONAL	OPTIONAL
SMFRS-500DH	500	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	HYDRAULIC	18-24 METER	540	45-55	OPTIONAL	OPTIONAL
SMFRS-600DH	600	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	HYDRAULIC	18-24 METER	540	55-65	OPTIONAL	OPTIONAL
SMFRS-800DH	800	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	HYDRAULIC	18-24 METER	540	65-70	OPTIONAL	OPTIONAL
SMFRS-1000DH	1000	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	HYDRAULIC	18-24 METER	540	70-75	OPTIONAL	OPTIONAL
SMFRS-1200DH	1200	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	HYDRAULIC	18-24 METER	540	75-80	OPTIONAL	OPTIONAL
SMFRS-1500DH	1500	MOUNTED	SQUARE	VERTICAL	DOUBLE DISC	HYDRAULIC	18-24 METER	540	80-85	OPTIONAL	OPTIONAL



**SOIL MASTER**  
AGRICULTURAL MACHINERY

HEAD OFFICE

Add: Fevzi Cakmak Mh. 10758 Sk. No: 16/G  
42050 Karatay/Konya/TURKEY

T: +90 332 290 00 20  
F: +90 332 290 00 19

FACTORY

Add: Büyükkayacık Osb, Yaylacık Cd. No:  
23, 42250 Selcuklu/Konya/TURKEY

T: +90 332 239 18 85  
T: +90 332 239 18 86  
F: +90 332 239 18 87

[www.soilmaster.com.tr](http://www.soilmaster.com.tr)



+90 (532) 137 01 74



[info@soilmaster.com.tr](mailto:info@soilmaster.com.tr)



SOILMASTER AGRICULTURAL MACHINERY



For detailed information about  
our products, you can scan the  
QR code by your device.